


ASSEMBLY INSTRUCTIONS STANDARD 1








ASSEMBLY INSTRUCTIONS STANDARD 2 AND 3






BOX ASSEMBLY - FOLD CORNER FLAPS TOWARDS MIDDLE OF BOX.




2

FOLD SIDE FLAPS UP AND THEN OVER TO MEET SLOTS AT THE BOTTOM. LOCK IN PLACE.






FRAME ASSEMBLY - FOLD TENSION FLAPS AND LIFT FILM. INSERT PRODUCT.



4

FOLD BOTH FLAPS WITH EQUAL FORCE DOWN AND UNDER THE FRAME.







FOLD SIDE PANELS UP 90 DEGREES AND HOLD TOGETHER.



HOLD PANELS TOGETHER AND INSERT INTO BOX. FOLD IN DUST FLAPS AND CLOSE BOX.






US09916N30 / US09950N10 2/28/14



ASSEMBLY INSTRUCTIONS STANDARD 12









ASSEMBLY INSTRUCTIONS STANDARD 8



1 FOLD TENSION FLAPS UP TO RELEASE FILM. LIFT FILM AND INSERT PRODUCT.









FOLD END PANELS UP AND HOLD IN PLACE WHILE INSERTING INTO THE BOX. PLACE ACCESSORIES BEHIND PANEL WITH HALF MOON.

