



# CHUTE



1. Insert Bag Evenly in the Collar



2. Position the peanut chute into the opening of the bag, pressing down to engage



3. Rotate the chute in a clock-wise direction to **securely fasten it**



4. Lift the cover to free the peanuts



 **02 9452-3566**  
**sales@getpacked.com.au**